

# Professional Juicer

stainless steel housing



©  
i  
i  
i  
i  
E  
B

BTJX20

# *Important Safeguards*

**When using electrical appliances, in order to reduce the risk of fire, electric shock and/or injury to persons, basic safety precautions should always be followed, including:**

## *For Your Safety*

***Read all instructions carefully, even if you feel you are quite familiar with the appliance.***

- To protect against electric shock, DO NOT IMMERSE any part of this appliance into water or any other liquid.
- Never leave the appliance unattended when in use.
- Children should be supervised to ensure that they do not play with the appliance.
- Do not allow the cord to hang over edge of a table or counter, or touch hot surfaces. Do not operate or place any part of this appliance on or near a hot gas or electric burner, or in a heated oven.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory and mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Do not operate any appliance with a damaged cord or plug; if the appliance malfunctions; or if it is dropped or damaged in any way.
- This appliance is for the use for which it has been manufactured. Any other use is to be considered inappropriate and therefore dangerous.
- Operate on a level surface. Operation on sinks, drain boards or uneven surfaces should be avoided.
- Before inserting the plug into the electrical socket, ensure the voltage of the socket corresponds to the value indicated on the rating label on the appliance.
- Switch off the power outlet and remove the plug before cleaning or when the appliance is not in use.

- Appliances are not intended to be operated by means of an external timer or separate remote-control system.
- Do not use outdoors.
- Do not use this appliance with an extension cord.
- This unit is intended for household use only.
- Store unit indoors in a dry location.
- Metallic objects such as knives, forks and spoons should not be placed in the appliance.
- Do not misuse the cord. Never carry the appliance by the cord or pull to disconnect it from the outlet. Instead, grasp the plug and pull to disconnect.
- Do not attempt to repair, disassemble or modify the appliance. There are no user-serviceable parts.
- Do not operate the juicer for more than 40 seconds at a time when juicing heavy loads and let it cool down for 1/2 minute before reuse. Never reach into the feeding tube with your fingers.
- Do not use any appliance for anything other than its intended use. This product is intended for household use only.


## *Compulsory Warning*

If the supply cord is damaged, the cord must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

This product has not been designed for any uses other than those specified in this booklet.

## *Save These Instructions*

# Features of Your Juice Extractor



# Getting to Know Your Juice Extractor

Congratulations on the purchase of your new Bellini Juice Extractor.

Before using your new appliance for the first time, it is most important that you read and follow the instructions in this booklet, even if you feel you are quite familiar with this type of appliance.

For future reference find a safe place to keep this booklet handy. Attention is particularly drawn to the section "Important Safeguards".

This appliance has been designed to operate from a standard domestic power outlet. It is not intended for industrial or commercial use.

## Before First Use

Before using the appliance for the first time, carefully unpack and remove all packaging material.

**Note: The appliance is equipped with a safety system. It won't work if the parts have not been mounted properly.**

1. Place the juice extractor in place.
2. Place the pulp container into the appliance by tilting it forwards slightly, then it is pushed home as shown.
3. Put the filter in the juice collector. Make sure the filter is fitted securely onto the driving shaft "click".
4. Hold the lid over the filter and lower it into position.
5. Snap the two clamps onto the lid to lock it into place "click". Make sure the clamps are locked into position on either side of the lid.
6. Slide the food pusher into the feeding tube by aligning the groove in the pusher with the small protrusion on the inside of feeding tube.

# How to Use Your Juice Extractor

**Note: The appliance will only function if all parts have been properly assembled and the lid has been properly locked in place with clamps.**

1. Wash the fruit and/or vegetables and cut them into pieces that fit into the feeding tube.
2. Make sure the juice jug (not included) has been placed under the spout.
3. Plug the appliance into a standard domestic power outlet and turn on the switch.
4. Put the pre-cut pieces in the feeding tube and gently press them down towards the rotating filter by means of the food pusher. After the flow of juice has stopped, and the filter has stopped rotating, switch the appliance off. Never insert your fingers or any object into the feeding tube.

## Care & Cleaning

- The appliance is easier to clean immediately after use.
- Do not use abrasive cleaning agents, scourers, acetone, alcohol, etc. to clean the appliance.
- All detachable parts are dishwasher safe.
- Switch the appliance off, remove the plug from the wall socket and wait until the filter has stopped rotating.
- Remove the dirty parts from the motor unit.

Disassemble the appliance in the following order:

1. Remove the food pusher;
  2. Open the clamps;
  3. Remove the lid.
- Remove the juice collector together with the filter.
  - Clean these parts with the cleaning brush in warm water with some washing up liquid and rinse them under the tap.
  - Clean motor unit with a damp cloth. Never immerse the motor unit in water nor rinse it under the tap.

## Specification

Voltage: 220-40V ac  
Frequency: 50HZ  
Power Input: 700W  
Protection Class: II

## Problem shooting

The appliance does not work.

The motor unit gives off an unpleasant smell the first few times the appliance is used.

The appliance makes a lot of noise, gives off an unpleasant smell, is too hot to touch, emits smoke etc.

The filter is blocked.

The filter touches the feeding tube or vibrates strongly during processing.

## Solution

The appliance is equipped with a safety system. It won't work if the parts have not been mounted properly. Check whether the parts have been assembled in the right way, but switch off the appliance before you do so.

This is not unusual. If the appliance continues to give this smell after a few times, check the quantities you are processing and the processing time.

Switch the appliance off and unplug it. Check with the service centre.

Switch the appliance off, clean the feeding tube and the filter and process a smaller quantity.

Switch the appliance off and unplug it. Check if the filter has been properly placed in the juice collector.

The ribs in the bottom of the filter should fit properly onto the driving shaft. Check if the filter is damaged. A loose grating disc or any other irregularity may cause malfunction.

# *Notes*

# *Notes*

# Warranty

The benefits conferred by this warranty are in addition to all implied warranties, other rights and remedies in respect of the product which the consumer has under the Trade Practices Act and similar State and Territory Laws.

The original purchaser of this Bellini product is provided with the following warranty, subject to the following conditions.

This product is warranted for a period of 1 year from the date of purchase for all parts defective in workmanship or materials. Should an instance occur where the product is deemed faulty, the product will need to be returned to the retailer where it was purchased to be replaced with the same product or product of equivalent value and type free of charge, or a refund issued. In order to obtain an exchange or a refund, proof of purchase must be presented to the retailer.

This warranty is in addition to all other rights and remedies available under the Trades Practices Act 1974 and other relevant State and Territory laws and shall not be taken as applying to exclude, restrict or modify such rights or remedies in any other matter whatsoever.

## WARRANTY CONDITIONS

1. This warranty is only valid for appliances used according to the manufacturer's instructions.
2. This appliance must not be modified or changed in any way.
3. Connection must be to the voltage requirements as specified in the ratings label located on the product.
4. The manufacturer does not accept liability for any direct or consequential damage, loss or other expense arising from misuse or incorrect installation and operation of the appliance.

5. Warranty will only be given where proof of purchase is provided, e.g. original invoice.
6. Not designed or warranted for industrial or commercial use.

## DO NOT SEND IN THIS WARRANTY

Fill out the following details and file with your purchase invoice.

## RETAIN & FILE WITH YOUR RECEIPT

Your Purchase Receipt/Invoice is proof of date of purchase. You must be able to present it at the place of purchase to obtain a replacement or a refund.

GSM International Ltd reserves the right to discontinue items, modify designs and change specifications without incurring obligation. Whilst every effort is made to ensure that descriptions, specifications and other information in this publication is correct, no warranty is given in respect thereof and the company shall not be liable for any errors therein.

Purchased from: \_\_\_\_\_

Co. Name: \_\_\_\_\_

Address: \_\_\_\_\_

Date of Purchase: \_\_\_\_\_

**NOTE: Consistent with our continuing product development policy, improvements may have been made which render the contents of this package slightly different to that shown.**

Cat. No. BTJX20  
November 2010

# G | S | M

Gerard Sourcing & Manufacturing

## GSM International Ltd.

GSM International Ltd has a policy of continual improvement throughout the product range. As such the unit contained within may differ slightly from the unit illustrated on the pack.

MADE IN CHINA for GSM International Ltd.



N1028