

EnerGI Nutrient Blender



bellini

BTGW930

Important Safeguards

When using electrical appliances, in order to reduce the risk of electric shock and/or injury to persons, basic safety precautions should always be followed, including:

For Your Safety

Read all instructions carefully, even if you are familiar with the appliance.

- To protect against the risk of electric shock, DO NOT IMMERSE the appliance, power cord set or plug in water or any other liquid.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory and mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Switch off the power outlet and remove the plug before cleaning or when the appliance is not in use.
- Do not operate any appliance with a damaged power cord or plug; if the appliance malfunctions; or if it is dropped or damaged in any manner.
- Do not allow the power cord to hang over the edge of a table or counter, or to touch hot surfaces.
- Do not operate or place any part of this appliance on or near a hot gas or electric burner, or in a heated oven.
- The use of attachments or accessories not recommended or sold by the manufacturer can cause electric shock or injury.
- Operate on a dry level surface; sinks, drainboards or uneven surfaces must be avoided.
- Do not use any appliance for anything other than its intended use. This product is intended for household use only.
- This appliance is intended to be plugged in a standard domestic power outlet only.

- Do not use outdoors.
- Never let the blender operate unattended.
- Make sure the blade is securely fastened to the accessories before you assemble them onto the motor unit.
- Make sure all parts are correctly mounted before you switch on the appliance.
- Do not remove accessories from the motor base when the blender is working.
- Do not exceed the quantities and processing times indicated in the instruction manual.
- Unplug the blender immediately after use.
- Do not misuse the power cord. Never carry the appliance by the power cord or pull it to disconnect from the power outlet. Instead, grasp the plug and pull to disconnect.
- Do not carry the appliance by the power cord.
- Do not attempt to repair or disassemble the appliance. There are no user-serviceable parts.
- Extreme caution is necessary when moving any appliance containing hot liquids.
- Wait until the appliance has been switched off before moving the EnerGI Nutrient Blender.
- Never microwave with the blade still attached. Remove the blade and twist on a shaker / steam top.
- When microwaving, beware of steam and use an oven mitt to remove hot cups from the microwave.
- Do not use party mugs in the microwave.
- Never keep the motor running for more than 30 seconds.
- This appliance is not intended to be operated by means of an external timer or separate remote-control system.
- Be careful if hot liquid is poured into the blender as it can be ejected out of the appliance due to a sudden steaming.
- Switch off the appliance and disconnect from supply before changing accessories or approaching parts that move in use.

FAILURE TO OBSERVE THESE CAUTIONS MAY RESULT IN DAMAGE TO THE APPLIANCE.

Warning

If the supply power cord is damaged, the power cord must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.







This product has not been designed for any uses other than those specified in this booklet.

Caution - BLADES ARE SHARP, HANDLE CAREFULLY. Avoid contacting moving parts. Keep hands, spatulas and other utensils, away from blades during operation to reduce risk of injury to persons, and/or damage to blender.

Warning - Injury Hazard:
Unplug the blender and ensure the blade is stopped completely before moving the cup or touching the blades. Failure to do so can result in broken bones, cuts or bruises.

Save These Instructions

Features of Bellini EnerGI Nutrient Blender



Getting to Know Your Bellini Nutrient Blender

Congratulations on the purchase of your new Bellini Nutrient Blender.

The Nutrient Blender is the ideal Multi Purpose Blender for chopping, grating, whipping and grinding. The unit is so versatile for its size; it can stay on the bench top all year round.

Before First Use

Before using your Nutrient Blender for the first time it is important that you read and follow the instructions in this use and care booklet, even if you feel you are familiar with this type of appliance.

Your attention is drawn in particular to the section dealing with IMPORTANT SAFEGUARDS. Find a safe and convenient place to keep this booklet handy for future reference. This appliance has been designed to operate from a standard domestic power outlet. It is not intended for industrial or commercial use. Carefully unpack the Nutrient Blender. Remove all packaging materials and either discard or retain for future use.

Ensure that the voltage of your electricity supply is the same as that indicated on the rating label on the appliance (220-240V). Remove the plastic accessories and wash in warm soapy water. Dry thoroughly and replace. Wipe over the exterior of the Motor Base with a damp sponge or cloth. Do not use abrasive cleaners.


How to Use Your Bellini Nutrient Blender

Choosing the Right Blade

Care is needed when handling cutting blades, especially when removing the blade from the cup, emptying the cup and during cleaning.

The Nutrient Blender comes with two blades: Pulverizing blade and Milling blade.

Pulverizing Blade Subassembly



Chopping - Foods like onions, garlic and carrots, And for making dips such as salsa or bean dip.

Blending - Pulverizes ice for smoothies, frozen cocktails and milkshakes.

Mixing - Pancake batters, muffins and quick breads are mixed in seconds.


Grating - Hard and soft cheeses and chocolate are grated in seconds.

Pureeing - Dishes such as hummus, all-natural soups, and baby food are creamy smooth in seconds.

Shaving Ice and Frozen Fruits - For tasty treats such as snow cones or fruit sorbets.

Grinding Meats - Delicious chicken and ham salads or pates are ground in seconds (Do not exceed 100 g when grinding).

Milling Blade Subassembly



Grinding and chopping, harder, single ingredient items such as:

Coffee beans
Nuts
Cinnamon sticks
Dried fruit

NOTICE:

- Do not use the MAX. level marking on the small cup for dry grinding / milling option as volume contained will not give the desired result
- For dry grinding / milling function only fill small cup to 1/3 of the max. level marking.

Operation

NOTICE:

- Never overfill the cups above the MAX level indication.
- Do not mash or grind heavy foods (e.g., potatoes) or stir thick mixtures (e.g., dough) in this product.
- Do not operate the product empty.
- Never use the blender for more than 30 seconds without interruption.

NOTE: The blender has a built-in safety lock feature, this ensures that you can only switch on the appliance while the cup and the blade subassembly are assembled on the motor base securely. If the appliance is correctly assembled, the built-in safety lock will be unlocked.

Using the Pulverizing Blade Subassembly:

1. Place the Motor Base on a flat, level, stable surface. Ensure the power cord is unplugged.
2. Clean and cut all solid ingredients into pieces small enough to fit and place into a Tall or Short Cup, then pour in any liquid ingredients.
3. Ensure the Gasket is seated properly in the Pulverizing Blade subassembly, then tighten the Pulverizing Blade subassembly clockwise onto the top of the Cup.
4. Turn the assembled cup upside down, place and lock it onto the Motor Base. You need to align the **f** symbol on the bottom edge of the Pulverizing Blade subassembly with the **▲** mark on the Motor Base and turn clockwise until it is firmly in place. The **f** symbol should align with the **▲** mark.

NOTE: Product will not operate unless BOTH the Cup and Blade subassembly are attached properly to the Motor Base.

5. Plug the power cord into 220-240V AC electrical outlet.
6. Press the Switch to activate.

NOTICE: Never run the appliance for more than thirty seconds at a time. Allow the motor to cool for one minute after each thirty seconds of operation. As it can cause permanent damage to the motor. If the motor stops working, unplug the Motor Base and let it cool for a few hours before attempting to use it again.





NOTICE: If the Blade is not running smoothly, stop the product and add some liquid, or reduce the solid ingredients in the Cup.

7. Shut the motor off by pressing the Switch again. Unplug the power cord from the electrical outlet immediately after use.
8. When the blade is stopped completely, unlock and remove the assembled Pulverizing blade subassembly and cup from the Motor Base.
9. Unscrew the Blade subassembly from the Cup. To disassemble the cup, follow the instructions above in reverse order and direction. Pour the contents into a separate container or screw a Sipping Ring onto the Cup to consume contents directly. For later consumption, screw a Storage Lid onto the Cup and place the Cup in your refrigerator.

Using the Milling Blade Subassembly:

1. Place the Power Base on a flat, level, stable surface. Ensure the power cord is unplugged.
2. Fill a Short Cup with the food that you wish to grind/chop. Cut large ingredients into pieces approximately 2cm before processing.
3. Screw the Milling Blade Subassembly onto the Cup until secure.

NOTE: Ensure that the Gasket, located on the inside bottom edge of the Milling Blade Subassembly, is in place.

4. Turn the assembled cup upside down, place and lock it onto the Motor Base. You need to align the  symbol on the bottom edge of the Milling Blade Subassembly with the  mark on the Motor Base and turn Cup clockwise until it is firmly in place. The  symbol should align with the  mark.

NOTE: Product will not operate unless BOTH the Cup and Blade subassembly are attached properly to the Motor Base.

5. Plug the power cord into 220-240V AC electrical outlet.
6. Press the Switch to begin grinding/chopping the contents. To prevent product overheating, dry ingredients must not be processed for more than 30 seconds at a time. Switch the product off and let it cool down to room temperature before you continue processing.
7. To stop grinding/chopping, press the Switch again. When the blade is stopped completely, unlock and remove the assembled Milling blade subassembly and cup from the Motor Base. Unscrew the blade subassembly from the cup.
8. If using the Short Cup for storing, screw a Storage Lid onto it to keep contents fresh.
9. Unplug the power cord from the electrical outlet when the product is not in use or is left unattended (not looked after or watched).

Care and Cleaning

CAUTION: Always ensure the product is unplugged from the electrical outlet before relocating, assembling, disassembling, or cleaning it and wait until it has cooled down sufficiently before cleaning. This product contains no user serviceable parts. Refer service to qualified service personnel.

NOTE:

- **Unplug the blender before you started cleaning it.**
- **Wait until the blender has cooled down sufficiently before cleaning it.**
- **All detachable accessories can be cleaned in dishwasher.**
- **Clean the motor base with a slightly damp cloth.**
- **Do not use scouring pads, abrasive cleaning agents or aggressive liquids such as petrol, alcohol or acetone to clean the appliance.**

1. Always wash immediately after use for easier cleaning. Don't let food dry on the cup as this will make cleaning difficult.
2. After you unplug the blender, detach the used accessories and parts, and clean them in warm, soapy water. Rinse all accessories and parts under a tap and dry thoroughly.
3. Wipe the motor base clean with a slightly damp cloth to remove any residue, and dry thoroughly. Never submerge the motor base in water or other liquid, or place in a dishwasher. Do not immerse the motor base in water or any liquid for cleaning.

Tips:

- Use a small brush (not included) to remove particles of food lodged underneath the blades.
- If some leftover particles dry onto the inside of the cup, fill the cup about 2/3 full with warm soapy water and attach the Milling Blade Subassembly. Place the cup and Blade Subassembly onto the Motor Base and press the Motor Button. Run the appliance for about 20-30 seconds to help loosen the stuck ingredients. Repeat the above step but use clean tap water. Empty blender and dry thoroughly.

- Store the product in a cool, dry place.

Caution: The Nutrient Blender attachments (Short Cup, Tall Cup, Lid and Ring) are able to be placed in upper rack of the dishwasher or alternatively they can be hand washed with warm soapy water and then rinsed.

Caution: Always make sure the gaskets are still inside after cleaning. The heat from some dishwashers can cause them to become loose and pop out.

CAUTION: Handle the blade carefully.

1. Do not immerse the motor base in liquid to prevent the risk of electric shock.
2. Do not use harsh or abrasive cleansers on any part of the appliance.
3. Do not use scouring pads, abrasive cleaning agents or aggressive liquids such as petrol, alcohol or acetone to clean the appliance.
4. Do not touch the sharp blades, they are extremely SHARP and may cause injury. Do not attempt to remove blades from the Blade subassembly for cleaning.

Specifications

Power Supply
Power Consumption

220-240V ~ 50Hz
600W

Note: As a result of continual improvements, the design and specifications of the product within may differ slightly to the unit illustrated from the packaging.

Recipes

Body Balance Blaster

- 2 handfuls spinach
- 1/2 cup raspberries
- 1 banana
- 6 almonds
- 3 tbs raw cacao

Fill to the MAX indication with spring water.
Juice away!

The Relaxer

- 1/2 raw beet
- 8 red seedless grapes
- 3 small broccoli florets
- 8 blueberries
- 1 tbs goji berries
- 1/2 inch of ginger root
- dash of coconut milk

Fill to the MAX indication with spring or coconut water.
Juice away!

Young at Heart

- 1 handful kale
- 1/2 avocado (pitted and peeled)
- 2 medium apricot
- 1 cup blueberries
- 8 walnut halves
- 1 kiwi fruit (peeled)

Fill to the MAX indication with spring water or almond milk.
Juice Away!

Sleepy Hollow

- 1 handful spinach
- 1 banana
- 1/2 cup raspberry
- 1/2 cup black berry
- 1 tbs pumpkin seeds
- 1 tbs sunflower seeds
- 1 tbs Chia seeds

Fill to the MAX indication with spring water.
Juice Away!

Glowing Beauty

- 1 handful swiss chard
- 1/2 cup pineapple
- 1/2 cup strawberries
- 1 tbs goji berries
- 8 cashews

Fill to the MAX indication with spring water or almond milk.
Juice away!

Strikingly Skinny

- 3 to 4 spinach leaves
- 1 banana
- 1/8 cup pumpkin seeds
- 1 orange (peeled)
- 1 stick of celery

Fill to the MAX indication with spring water
Juice Away!

NOTES

NOTES

G | S | M

Gerard Sourcing & Manufacturing

GSM International Ltd.

Consumer Service Centre : 1300 373 199

GSM International Ltd has a policy of continual improvement throughout the product range.
As such the unit contained within may differ slightly from the unit illustrated on the pack.

MADE IN CHINA for GSM International Ltd.

Cat. No. BTGW930
October 2014