

Diamond 1.7 Litre Cordless Kettle

stylish diamond facet finish



Bellini

BTK820

Important Safeguards

When using this electrical appliance, the following basic safety precautions should always be followed:

- Please read these instructions before operating and retain these for future reference.
- Before connecting the kettle to the power supply, check that the voltage indicated on the appliance corresponds with the voltage in your home. If this is not the case, contact your local qualified technician and DO NOT use the kettle.
- Use this kettle with the supplied base only.
- If the supply cord or any part is damaged, cease use of this appliance immediately to avoid a hazard.
- Do not hang the power cord over the edge of table or allow the cord or the user to touch the external part of the enclosure after or during operation.
- Place the appliance on the flat surface. Do not place on the heated surface or near a hot gas or electric burner or oven.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with appliance.
- To protect against electric shock, do not immerse the cord, plug, power base and kettle in water or other liquid.
- After boiling, please avoid touching the steam coming from the spout and hot water. Also, do not open the lid without allowing the appliance and water to cool.
- Take care when pouring hot water.
- Unplug it from the power outlet when not in use.
- This product is for boiling water only. Do not attempt to heat any other liquids.
- Only use the handle when handling this appliance.
- This appliance has been manufactured for the purpose of indoor, household use only. Do not use in a commercial or industrial environment.
- Take care when handling or moving this appliance when water is still in the container.
- The use of any accessories or attachments that are not recommended by the appliance manufacturer may result in fire, electric shock, personal injury or damage to this appliance or the customer's property.
- Do not place this appliance on a metal surface whilst in use.
- Please do not boil when the water amount is less than 0.5 Liter, this will result in damage to the appliance.
- Do not overfill. The water level must not exceed the maximum water level mark (1.7 Liter). If the kettle is overfilled, boiling water may be ejected.
- Prior to operating this appliance, please ensure that the lid is properly closed.
- Press down the On/Off switch gently when you are ready to operate the appliance.
- Do not remove the lid while the water is boiling.
- When cleaning, allow the appliance to cool first then wipe with a slightly damp cloth.
- This appliance is intended to be used in household and similar applications such as:
 - Staff kitchen areas in shops, offices and other working environments;
 - Farm houses;
 - By clients in hotels, motels and other residential type environments;
 - Bed and breakfast type environments.
- Save these instructions.

CAUTION

- **Do not operate the kettle on an inclined plane. Do not operate the kettle without water inside. Do not move the kettle while it is switched on.**
- **Ensure that the kettle is switched off before removing it from its stand. The appliance must not be immersed in water or any other liquids.**
- **If the supply cord is damaged, it must be replaced by the manufacturer or similarly qualified persons in order to avoid a hazard.**
- **The base and exterior of the kettle must not become wet.**
- **Do not operate the kettle on an inclined surface.**

Description of Kettle



Operation


Warning: Do not operate the kettle without enough water filled.

It is recommended to operate the kettle several times following the below instructions and discard the boiled water before first use. This will remove any material, residue or dust from the appliance, which may exist from the manufacturing process.

1. Open the lid by pressing down the Lid opening button and fill with fresh cold water into the kettle up to the desired water level without exceeding the maximum level. Then close the lid ensuring that it is firmly closed.

The Maximum water level is indicated inside the kettle and is marked by the word "1.7L -MAX". The maximum amount of water to be used is indicated by the "MAX FILL" level in the right figure. Do not overfill the kettle as water may eject from the kettle.

The minimum amount of water is 0.5L. Please ensure the water level reaches at least the bended part of tube inside the kettle. The minimum water level is indicated by the "MIN FILL" level in the figure below.



Caution: The filled water level must be between "1.7L" and "0.5L". Failure to keep the water level within this range may damage the element, kettle components or water may eject from the appliance when boiling.

2. Place the kettle on the Power Base and connect it to the power supply. Position the kettle so that the spout of kettle is facing away from you and any other materials that could be damaged by hot steam.
3. Press the On/Off switch down and the lamp will be illuminated. Do not open the lid while the water is boiling.
4. The Power will cut off automatically and the switch will return to the OFF position when the water has boiled. The indicator lamp will switch off. Unplug the kettle after use immediately.
5. The boiling process can be terminated at any time by lifting the kettle off the Base or by lifting the On/Off switch up.
6. Lift the kettle from the power base and then pour the water.

Note: Operate carefully when pouring the water from your kettle as boiling water may result in scald, besides, don't open the lid while the water in the kettle is hot.

CAUTION

- Take care and keep the kettle level when removing it with boiled water, otherwise, hot water may be leaked and burn your body.
- Never operate the appliance empty. If this occurs, the thermal cut-off inside the kettle would operate to cut off power automatically. Unplug the appliance and let it completely cool down.
- Beware of steam coming from the spout or lid especially during refilling. Never open the lid when the kettle is boiling.
- The kettle switches off automatically when the water has boiled. Always keep the lid closed when pouring the water out.
- If the kettle has recently boiled and switched off automatically, it may be necessary to wait for approx. 15 seconds before the switch can be reset.
- Beware of steam and scalding!

Care and Cleaning

CAUTION: To prevent damage to the appliance, do not use alkaline cleaning agents when cleaning, use a soft cloth and a mild detergent.

1. Remove the plug from the wall outlet and let the appliance completely cool down before cleaning.
2. Do not immerse power cord, kettle and Power Base in water or any other liquids.
3. Do not use abrasive cleaners or harsh chemicals to wipe the housing.
4. Periodical descaling is needed. The interval of descaling depends on the quality of water in your living area and the frequency that you use the kettle.
5. The power cord can be wound around the bottom of the base for storage.
6. Do not attempt to dismantle the kettle or power base. No user serviceable parts inside it. In the event of a malfunction, contact your local qualified service technician for advice.

NOTE: This kettle has an overheating protector in the kettle. In the event of overheating, such as operating without water in the kettle or the water being boiled-dry, the kettle will automatically shut down to prevent further damage.

Specifications

- Power supply..... AC 220-240V~50Hz
- Power consumption.....1850-2200W
- Capacity.....1.7L

Notes

G | S | M

Gerard Sourcing & Manufacturing

GSM International Ltd.

Consumer Service Centre : 1300 373 199

GSM International Ltd has a policy of continual improvement throughout the product range.
As such the unit contained within may differ slightly from the unit illustrated on the pack.

MADE IN CHINA for GSM International Ltd.



N1028

Cat. No. BTK820
December 2013